





# Carron

## Wall Stay Fitting Instructions


### Contents



Attach Spigot to the wall through central hole




Attach the Collar to the Spigot



Screw the Threaded Bar into the Collar as far as it can go in.


4

Distance to measure




Measure the distance from the wall to where the back of the radiator is to sit, as shown above. The Clamping Plate can be used in either a vertical or horizontal position. Radiators with a smaller space between each section, the Clamping Plate should be positioned Vertically. Radiators with a larger space between each section, the Clamping Plate should be positioned horizontally. Install the red washer, then the Thistle head will screw through the un-threaded clamping plate.

5




The radiator should now be moved into position, making sure that it is sat against the Clamping Plate.

6



Aerial View



Attach the Clamping Plate onto the Threaded Bar followed by the Collar. Tighten to the Clamping Plate. The Threaded Bar can now be cut



[www.carronheating.co.uk](http://www.carronheating.co.uk)

T: 01400 263319 | E: [sales@carronheating.co.uk](mailto:sales@carronheating.co.uk)